

G-CKZD EuroFOX CHECK LIST

PRE START UP CHECKS

1. Brakes – ON.
2. Area / direction – CLEAR & SAFE.
3. Harnesses and doors – SECURE.
4. Loose Items – STOWED.
5. Headsets – ON.
6. Carburettor heat – SET.
7. Heater – SET
8. Oil flap – SET
9. Throttle – FULLY CLOSED (friction set)
10. Flaps – NEUTRAL.
11. Wing tanks – One or both ON as required.
12. Main fuel tap – ON.
13. Magnetos – OFF.
14. Master switch – OFF.
15. All power switches – OFF.

G-CKZD EuroFOX CHECK LIST

ENGINE START

1. Master switch – ON.
2. Ensure altimeter initialises correctly.
3. Hobbs reading – RECORD.
4. Low Fuel Warning Lamp – TEST.
5. Boost pump – ON (check pressure rises then OFF when stable)
6. Throttle and choke – AS REQUIRED.
7. Radio, Transponder and Gyro displays – OFF.
8. Strobes – ON.
9. Area – ALL CLEAR.
10. Stick – FULLY BACK!
11. Magnetos – ON.
12. **Shout** “CLEAR PROP” - pause 3 to 5 seconds.
13. Engine – START – monitor oil pressure & set 2000 rpm when soft start period ends.
14. Choke – OFF (if used) control RPM.
15. Power switches – Switch ON the following:
 - Radio,
 - Transponder,
 - Gyro,
 - GPS supply – if required.
16. Landing lights and boost pump– CHECK OFF
17. Radio – ON Check / Set: Active, Standby frequencies and Vol settings.
18. Transponder – ON Check / Set: mode “STANDBY” & active squawk to 7000.
19. Radio – CALL & RECORD Runway and pressure setting.
20. Set QNH and runway heading on Gyro and QFE or QNH as appropriate on Altimeter.
21. Log brakes off time.

TAXI TO RUN UP AREA.

1. Speed – MAX 8kts (Brisk walking pace).
2. Controls – DEFENSIVE POSITIONS.
3. Check – BRAKES, STEERING, SLIP BALL, COMPASS.

G-CKZD EuroFOX CHECK LIST

PRE FLIGHT (VITAL ACTIONS)

1. Park – IN TO WIND.
2. Brakes – ON.
3. Throttle – 2000 RPM
4. Controls – CHECK (full & free, correct sense, including flaps)
5. Harnesses and doors – CHECK.
6. Loose items – STOWED.
7. Flight instruments – CHECK.
8. Engine Instruments – CHECK.
9. Magnetos – CHECK (3800 to 4000 RPM)
10. Idle – CHECK (then return to 2000 RPM)
11. Fuel contents – CHECK (contents and tank selection as required)
12. Main fuel tap – CHECK ON.
13. Boost pump – ON (monitor pressure during switch on)
14. Flaps – SET.
15. Trim – SET
16. Transponder – ACS
17. Landing Lights – ON.
18. Oil flap – SET .
19. BRS – REMOVE safety pin
20. Taxi to hold point.

G-CKZD EuroFOX CHECK LIST

PRE TAKE OFF FINAL CHECKS AT HOLD POINT AND TAKE OFF ROLL

1. Check – Fuel, Flap, Trim, Transponder, oil flap (partially opened) Landing Lights, Ts & Ps.
2. Check – BRS armed.
3. Check – all clear for take off.
4. Log take-off time.
5. Call “Lining up runway xx” pause.
6. Double check final approach.
7. Line up.
8. Assess wind.
9. Select abort point,
10. Check brakes OFF.
11. Check – Full power during take off roll (min 5000 RPM)
12. Check – ASI alive.

AFTER TAKE OFF

1. Monitor and control air speed before and during climb.
 - Minimum 48kts before climb.
 - 63 kts in climb for best AOC (V_x) 66 kts max (V_{i0})
2. Flaps - NEUTRAL at 200 – 300 feet, then climb out at 70 to 80 kts.
3. Engine temperatures and pressures – CHECK within limits, regulate with oil flap as required.
4. Boost pump OFF above 2000 feet AGL (observe fuel pressure, especially if using a high power setting, be prepared to turn back on)

G-CKZD EuroFOX CHECK LIST

ON ROUTE: – FRED A – CHECKS

- **F**uel – Used, remaining, endurance.
- **R**adio – Active and standby frequencies set as required.
- **E**ngine – Temperatures and pressures healthy, regulate oil temperature with oil flap.
- **D**irection – Compass heading, or ground track from HORIS as appropriate.
- **A**ltimeter – Correct pressure set, maintaining planned altitude.

AIRFIELD APPROACH

1. Fuel – CHECK contents sufficient and tank(s) selected.
2. Radio – SET to airfield frequency.
3. Call for airfield information.
4. Altimeter – SET to airfield QFE.
5. DI – SET to runway heading.

OVERHEAD JOIN

1. Boost pump ON before descending below 2,000’.
2. Fuel sufficient and tank selected.
3. Carburettor heat – To suit conditions.
4. Oil flap – To suit conditions.
5. Call “Dead-side, descending for runway xx”
6. Look out for and integrate with circuit traffic.
7. Call “Joining x-wind for runway xx”

G-CKZD EuroFOX CHECK LIST

DOWNWIND

1. Make downwind call, abeam upwind threshold.
2. **LOOK-OUT!** Monitor activity in circuit/runway – Visual and radio traffic.
3. 4000 – 4300 RPM – clean – (around 80 – 90kts) dependent on circuit traffic, trim.
4. Down-wind checks: - **BFFICH** -
 - **B**rakes, firm and OFF.
 - **F**uel, Sufficient for a go around, boost pump on, pressure healthy.
 - **F**laps, check and consider.
 - **I**nstruments, Flight and engine, Ts & Ps healthy.
 - **C**arburettor heat, CHECK set as required for conditions.
 - **H**arness & Hatches, secure.
5. Use drift to estimate relative wind speed and direction and determine type of approach to be used.

BASE LEG

1. Reduce power to approx 3000 RPM and raise nose to maintain level flight.
2. Flaps set stage 1 once below V_{FE} .
3. Maintain level flight and allow speed to reduce to 63 kts.
4. Plan descent, (glide or powered) to approx 500-700' before BASE to FINAL turn.

FINAL

1. Make FINAL call.
2. Power – as required for approach type.
3. Speed – 55 kts or as required for glide, within flap limiting speed of 66kts.
4. Flaps – SET stage 2 as required.
5. 50 kts over threshold.
6. At 200' Clear to land, stable approach? **Be prepared to GO AROUND if in any doubt!**
7. Fully held off landing, with a nose high attitude at minimum speed, subject to wind.
8. Keep nose-wheel off ground as long as possible!

G-CKZD EuroFOX CHECK LIST

RUNWAY CLEAR CHECKS

1. Make runway vacated call.
2. Log landing time.
3. Log flight time from VSI.
4. BRS – REPLACE safety pin.
5. Flaps – RETRACT (neutral).
6. Boost pump – OFF.
7. Landing Lights – OFF.
8. Oil flap – As required.

PRE SHUTDOWN

1. Brakes – ON (Log time)
2. Power switches – ALL (EXCEPT STROBES!) OFF.
3. Magneto – CHECK at 2000 RPM.

SHUTDOWN

1. Magneto – 1 OFF at 2000 RPM.
2. Throttle to Idle, magneto – 2 OFF, at minimum revs, do not sustain low revs.
3. Strobes – OFF.
4. “Low Fuel Warning Lamp” – TEST.
5. Hobbs meter reading – RECORD.
6. Master switch – OFF, remove key.
7. BRS – DOUBLE CHECK safety pin is securely in place.
8. Secure aircraft facing into wind.
9. Secure controls as required.
10. Return keys, do not put in your pocket!!!

G-CKZD EuroFOX CHECK LIST

EMERGENCY SHUTDOWN

- T** Throttle closed
- I** Ignition and magnetos OFF
- F** Fuel OFF
- F** Flaps DEPLOYED
- S** Security, Harnesses Hatches

EXTREME MANOEUVRE

- H** Height sufficient
- A** Airframe (Flaps add trim set)
- S** Security and loose items
- E** Engine Temps and Pressures
- L** Location (ABC)
- L** Lookout